

# HARKEN®

## INSTALLATION SHEET

### 1985 6:1 Dodger Block Conversion kit Fits 1893, 1882, 1983

1251 East Wisconsin Avenue • Pewaukee, WI 53072 U.S.A.  
Telephone: (262) 691-3320 • Fax: (262) 691-3008  
Web: [www.harken.com](http://www.harken.com) • Email: [harken@harken.com](mailto:harken@harken.com)

#### Parts

- 1 Port Side Control
- 1 Starboard Side Control
- 1 Tube Blue Loctite®

**Instructions:** Remove the three phillips screws holding the sheave assembly to the base.

**1982 or 1983** - Remove the spacers and cam plate.

1. Place the mylar isolator on the base, then place the dodger block on top of the mylar. Line these up with the forward holes, the ones closest to the bumper.

2. Use blue Loctite on the screws and install the sheave assembly so the becket end is towards the bumper.



## **Maintenance**

Harken equipment is designed for minimal maintenance, but some maintenance is required to give the best service and to comply with the Harken limited warranty.

In general, the most important aspect of maintenance is to keep your equipment clean by frequently flushing with fresh water.

In corrosive atmospheres, stainless parts may show discoloration around holes, rivets and screws. This is not serious and may be removed with a fine abrasive.

With the exception of winches, do not use grease unless specifically recommended in the instruction sheets.

Many Harken products are provided with specific instruction sheets that detail maintenance procedures. Instruction sheets are available at no charge by contacting Harken or a Harken distributor.

## **Warranty**

See the Harken catalog for full maintenance and warranty information.