

# **HARKEN®**

## **RigTune Pro Digital Rig Tension Meter**

- Tensiomètre de gréement numérique • Digital Riggspannungsmessgerät
- Misuratore digitale di tensione sartie e strallo • Medidor digital de tensión de jarcias

### **INSTRUCTION SHEET SUPPLEMENT**

1251 East Wisconsin Avenue • Pewaukee, WI 53072 U.S.A.  
Telephone: (262) 691-3320 • Fax: (262) 691-3008  
Web: harken.com • Email: harken@harken.com

Only measure tension of stays where both ends are fixed. Meter is not accurate if one end is free to move as in a mainsheet or hanging object.

Measure tension at a point that is at least 2' (.5m) from terminal.

**Important: When rotating handle, use index finger to avoid excessive force.**

Note number shown on handle. Rotate handle to same number each time you measure the same diameter wire. Record numbers below or on inside of box. Numbers on handle do not refer to wire sizes; they are for reference only.

| <b>Wire Diameter</b> | <b>Handle Number</b> |
|----------------------|----------------------|
|                      |                      |
|                      |                      |
|                      |                      |
|                      |                      |
|                      |                      |