

# HARKEN®

## INSTALLATION SHEET

### 599 Adjustable Traveler Stop

1251 East Wisconsin Avenue • Pewaukee, WI 53072 U.S.A.  
Telephone: (262) 691-3320 • Fax: (262) 691-3008  
Web: [www.harken.com](http://www.harken.com) • Email: [harken@harken.com](mailto:harken@harken.com)

The plastic screw in your 599 Adjustable Traveler Stop is designed to strip before you damage the track by overtightening. Additional replacement screws are available. Order part HCP 186.

### How to Replace Damaged Plastic Screw



To engage new screw, grip it and press down gently while turning it **counter-clockwise** slowly.



When the screw “pops” into threads, turn **clockwise** gently. If the screw does not engage easily, repeat the first step above. **Do not force screw on the first turn.**



Turn clockwise with winch handle to tighten. ***Do not over-tighten or push down on the end of the winch handle when turning. This will strip the screw threads.***

### **Maintenance**

Harken equipment is designed for minimal maintenance, but some maintenance is required to give the best service and to comply with the Harken limited warranty.

In general, the most important aspect of maintenance is to keep your equipment clean by frequently flushing with freshwater.

In corrosive atmospheres, stainless parts may show discoloration around holes, rivets and screws. This is not serious and may be removed with a fine abrasive.

### **Warranty**

See Harken catalog for full maintenance and warranty information.